






MONTE RTV STOLÍK 2S

Montážny návod / Montageanleitung / Mounting instruction / Инструкция сборки




A x 27

(8x36)



B x 26



C x 30
(15x12)





D x 56




E x 2 kpl


G x 2




F x 18



J x 1



K x 30




W1 x 12
(fi 3,5 x 13 USKB)




W2 x 12
(fi 3 x 25 USKB)




W3 x 2
(fi 4 x 25 USKB)



KROK 1




KROK 2




KROK 3


KROK 4




KROK 5




KROK 6




KROK 7




KROK 8




KROK 9



KROK 10



KROK 11



KROK 12

