

Montážní návod

KENTAKI




IDENTO

A	B	C	D
1	S320-006	596	188
2	S320-107	1800	370
3	S320-108	1800	370
4	S320-205	612	392
5	S320-206	612	392
6	S320-303	568	370
7	S320-304	567	366
8	S320-507	408	180
9	S320-508	408	180
10	S320-509	433	80
11	S320-510	694	80
12	S320-511	433	80
13	S320-906	1826	595
14	S320-907	526	348
15	S320-561	350	120
16	S320-562	350	120
17	S320-5541	511	120
18	S320-5542	333	60



S320-REG1D1S

S320-REG1W1S





S320-REG1D1S

A	B	C	D
19	S320-005	1600	596







S320-REG1W1S

A	B	C	D
19	S320-024	1600	596







3x a44	3x b19	12x d1	8x e8	4x e19	6x e2	6x e26	6x e3	14x f1
4x e1	1x j29	1x j11	60x l1	2x n40	2x c35/2	2x c35/1	4x p46	6x p51
8x r1	1x r15	9x r42	6x p8	1x w45/CL	1x w45/CR	1x w45/DL	1x w45/DR	1x z1
1x n26/1	1x p38	4x s2	6x s4	1шт. f35	1шт. p17			


1




2




3



4



5



6

