





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató

SYNTIA

?




FUTON II



2-9


LMBK II



10-19



D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



2/19

Name-Naam-Nazwa-Ісiм-Название-Nom-Nome-Jméno-Názov-Név-Denumire

SYNTIA FUTON II



A1 x 2



A2 x 2



A3 x 18



A4 x 8



A5 x 12




A6 x 2




A7 x 2



A8 x 4



A9 x 6



A10 x 2



A11 x 2



A12 x 2



A13 x 6



A14 x 4










A15 x 3



E1 x 2




E2 x 4



Service-Dienstverlening-Serwis-Servis-Сервисная Служба-Assistenza-Szerviz





Typ-Type-Típ-Típ-Tipo

A1	A8	A15	L4
A2	A9	E1	L5
A3	A10	E2	L6
A4	A11	F	L7
A5	A12	L1	
A6	A13	L2	
A7	A14	L3	

























1











3/19



2









5


6/19



6




7




7


7/19




8




9




*1




*2







*3



*?




*?





D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



10/19

Name-Naam-Nazwa-Имя-Название-Nom-Nome-Jméno-Názov-Név-Denumire

















SYNTIA LMBK II

RM



A1 x 2	A2 x 2	A3 x 18	A8 x 5	A9 x 6	A12 x 2	A13 x 6	A14 x 4
A16 x 20	A17 x 4	A18 x 6	A19 x 4	A20 x 2	A21 x 2	A22 x 4	A23 x 1
A24 x 1	A25 x 1	A26 x 6	A27 x 2	A28 x 1	E1 x 2	E2 x 4	F x 1

WPM 8x35	US 5x25	WPM 8x20	US 5x20	M6 x 18	WPM 6x50
US 5x50	WPM 6x70	8 x 40	WPM 6x35	L - 790	f-50 h-28



Service-Dienstverlening-Serwis-Servis-Сервисная Служба-Assistenza-Szerviz







Typ-Type-Típ-Típus-Tipo

A1	A14	A22	E2	L8
A2	A16	A23	F	L9
A3	A17	A24	L1	L10
A8	A18	A25	L2	L11
A9	A19	A26	L3	L12
A12	A20	A27	L4	L13
A13	A21	E1	L7	L14












1




11/19



2




3





4

12/19




5







14/19






L15




Ⓕ




L2








11




12







D - Montageanleitung GB - Assembly instructions NL - Handleiding voor de montage
PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



17/19

Name-Naam-Nazwa-Іsím-Название-Nom-Nome-Jméno-Názov-Név-Denumire

LMBK II

RM

WPM 8x50



A29 x 4

SMM 8x60



A30 x 3

M8



A31 x 6

M8






A32 x 3






M8



A32 x 3



15



Service-Dienstverlening-Serwis-Servis-Сервисная Служба-Assistenza-Szerviz

Typ-Type-Típ-Típ-Tipo-Tipo

A29

L17

A30

A31

A32

A33



L15

L16






16


18/19




17



*1



*3



*2

