

VORSICHT!

Nicht springen

ATTENTION!

Do not jump




POZOR!

Neskákat








POZOR! UWAGA!



Neskákat'

Nie skakać




4x


A		Ø10x40mm	12
B		Ø8x30mm	32
C		4,0x30mm	46
D		3,0x16mm	16
E		7,0x50mm	20
F		7,0x80mm	06
G			01

H			12
I			08


01




02




03




04




05




06




07






08





09




10 4x



11



12



VORSICHT!
Nicht springen

ATTENTION!
Do not jump

POZOR!
Neskákat

POZOR!
Neskákat'

UWAGA!
Nie skakać